


WESTERN STATES METAL ROOFING

(877) 787-5467 • WESTERNSTATESMETALROOFING.COM

NARROW GROOVE

INSTALLATION GUIDE WITH TRIM, FLASHINGS AND DETAILS



Phoenix: 901 W Watkins St., Phoenix, AZ 85007 ☎ (602) 495-0048 ⊠ sales@westernstatesmetalroofing.com Tucson: 4975 E. Drexel Rd., Tucson, AZ 85706 ☎ (520) 574-4247 ⊠ tucsonsales@westernstatesmetalroofing.com



Narrow Groove Installation, Flashings & Shop Drawing Detail Guide

Section	Page
Notes to Designer /Installers	1
Fastener Placement and Selection	2-3
T-Groove Panel Options	4-7
T-Groove Profile Reveals	8-11
T-Groove Stiffening Options	12-16
T-Groove Perforated Panel	17
Key Wall Plan	18
Key Flashing / Trims	19-20
Soffit End Splice Detail	21
Wall Splice Detail	22
Soffit End Wall Detail	23
Alternate Soffit End wall	24
Soffit to Wall Drip Detail	25
Horizontal Siding End Wall Detail	26
Vertical Siding End Wall Detail	27
Parapet Wall Detail	28
Splice/ Sill Detail	29
Base Trim Detail	30
Door/ Window Sill & Head Detail	31
Door / Window Jamb Detail	32
Door / Window Sill Detail	33
Outside Corner Detail	34
Inside Corner Detail	35
Custom Outside Corner Detail	36

Table of Contents

Section	Page
Custom Inside Corner Detail	37
Soffit to Wall Horizontal Detail	38
Parapet Wall Horizontal Detail	39
Splice /Sill Horizontal Detail	40
Base Horizontal Detail	41
Window/ Door Head Horizontal Detail	42
Window/ Door Jamb Horizontal Detail	43
Window/Door Sill Horizontal Detail	44
Outside corner Horizontal Detail	45
Inside Corner Horizontal Detail	46
Notes	47
Custom Trim	48
Design Considerations	49
Contact Information	50

Installation, Flashings & Shop Drawing Detail Guide

Notes to Designer and Installers

The details contained in this guide are proven industry details and are intended to be used as a design aid and installation guide. It does not depict all situations that may be encountered on all projects. Modifications are the responsibility of the designer/ owner/ installer. Consideration should be given for Fit for Purpose, Building use, Climate conditions such as temperature, snow, wind, and moisture, Governing Building Codes, and Maintenance. It is highly recommended that all trims and flashings be of the same material as the panels (metal, gauge, finish) to ensure long term performance and durability. Where possible, flashing edges should be hemmed to strengthen the edge and protect the cut edge from exposure.

Framing and Substrates

T-Groove[®] panels are used over all type of substrates like Steel Framing, open purlins, spaced sheathing, and wood surface such as plywood. Most details in this guide are shown with panels attached to Solid Wood Decking.

Note on Underlayment

Not all conditions require an underlayment, However metal siding is susceptible to Condensation and it is recommended that an appropriate underlayment be use on all wood substrates to protect the structure during installation. For added protection from rain and snow, it is recommended to use Sharkskin[®] Ultra and Sharkskin[®] Ultra SA.

Technical Assistance

Contact your WSDI sales or technical representative for any additional information or assistance.

Oil Canning

Oil canning is a condition common with flat metal surfaces. This waviness is caused by steel mill tolerances, forming, variations in the structures surfaces, and hardness of the steel. Measures are taken at the roll forming process, like profile design, steel gauge, corrective leveling, to minimize the effects of oil canning. Oil Canning is a Characteristic of steel and can not be eliminated totally and therefore is not reason for rejection of the panels.

Job Site Storage

While waiting to be installed on the job site, Storage of panels, trim crates, and flat sheet should be sloped in order to allow for proper moisture run off. One end should be elevated so as not to allow ponding of water on the metal surface. When using tarps for protection, proper ventilation should be provided to prevent condensation. Moisture or condensation that is trapped inside a bundle can lead to white rust on sheeting.

References

For other installation techniques and details, The Sheet Metal and Air Conditioning Contractors National Association Inc. (SMACNA) and NRCA manuals are great resource for working with sheet metal.

Installation, Flashings & Shop Drawing Detail Guide

Fastener Selection

Notes to Installers:

Fastener Selection will vary depending on type and thickness of substrate.Design Calculations for clip spacing should be completed by the design engineer.The use of Butyl tape mastic, Butyl sealants and Curing Sealants is always recommended to insure weather tight installation.


Panels and flashings should never be installed in contact with dissimilar metals. Use only those flashings and accessories designed for use with this panel.

Panel clip attachment screws must be long enough to fully penetrate through roof deck substrate or penetrate solid lumber at least one inch.

Exposed Trim Fasteners should have sealing washers and be coated to provide protection against corrosion.

Screws must be properly driven to ensure holding strength and proper seal. (see diagram) Recommended drill speed is 2000rpm. Improper setting of drill speed can lead to snapping of screw heads.

Pre drilling of screw holes may be necessary with heavy gauge metals.




Installation, Flashings & Shop Drawing Detail Guide

Fastener Selection

Description

Application

14 x 7/8" Lap Self tap 14 x7/8 Lap Stainless Used to attach Trims . Stainless to be used with A606-4 Steel



#10-12 x1" Pancake head Wood #10-12 x 1" SD PH Self Driller Steel Used to attach Panel clips. Used to secure trims to substrates. Also available in Stainless Steel.



1/8" Stainless Rivets

Used for Trim to Trim attachment or trim to wall panels.





Stainless Screws #10 x1 x1/4" Wood Drillers #10 x 1.5 x ¹⁄4" #10 x 2" x ¹⁄4"


Used for panel attachment for panels made with A606-4 Steel




The table above shows the panel fasteners provided by WSD. Special order screws are available.














www.MetalDeck.com






































901 W. Watkins St. Phoenix, AZ 85007 www.MetalForRoofing.com www.RustedRoofing.com www.MetalDeck.com

Phone: (602) 495-0048 Fax: (602) 261-7726 877-PURLINS (787-5467)


REV: PANEL TYPE: DETAIL #: NARROW GROOVE TG-WSD-W16


DETAIL


5/15/22

DATE:

А











CONTINUOUS CLEAT (WS-513)


			GAUGE:	COLC	DR:		
			LENGTH:	FINIS	SH:		
*** WSMR R	ECOMMENDS SHARKSKIN [®] ULTRA OR SHARKSKIN [®] ULTR	A SA	MATERIAL:				
Western States	Metal Roofing		PARAPET WAL	L			
901 W. Watkins St.	Phone: (602) 495-0048		HORIZONTAI	-			
Phoenix, AZ 85007	Fax: (602) 261-7726		DETAIL		A	5/15/22	
www.MetalForRoofing.com	877-PURLINS (787-5467)		PANEL TYPE:		REV:	DATE:	
www.RustedRoofing.com www.MetalDeck.com			NARROW_GROOVE_/ T-GRO	DOVE®	detail # TG-W		25

















NOTES:			
Western States Metal Roofing	1		<u> </u>
901 W. Watkins St. Phone: (602) 495-0048	NOTES	A	5/15/22
Phoenix, AZ 85007 Fax: (602) 261-7726 www.MetalForRoofing.com 877-PURLINS (787-5467)	PANEL TYPE:	REV:	DATE:
www.RustedRoofing.com www.MetalDeck.com	NARROW GROOVE	detail # TG-W	#: VSD-MN27

CUSTOM TRIM

	GAUGE:	COLO	DR:		
	BREAKS:	FINIS	SH:		
	LENGTH:	STR	ETCH OL	JT:	
	MATERIAL:	MATERIAL:			
Western States Metal Roofing	CUSTOM TRIM NAME	2:			
901 W. Watkins St. Phone: (602) 495-0048					
Phoenix, AZ 85007 Fax: (602) 261-7726			A	5/15/22	
www.MetalForRoofing.com 877-PURLINS (787-5467)	PANEL TYPE:		REV:	DATE:	ł
www.RustedRoofing.com www.MetalDeck.com	NARROW G	ROOVE	DETAIL # TG-W	^{≠:} /SD-CT28	34

Installation, Flashings & Shop Drawing Detail Guide

Special Design Considerations

The details contained in this guide are proven industry details and are intended to be used as a design aid and installation guide. It does not depict all situations that may be encountered on all projects. Modifications are the responsibility of the designer/ owner/ installer.

Consideration should be given for Fit for Purpose, Building use, Climate conditions such as temperature, snow, wind, and moisture, Governing Building Codes, and Maintenance.

It is highly recommended that all trims and flashings be of the same material as the panels (metal, gauge, finish) to ensure long term performance and durability. Where possible, flashing edges should be hemmed to strengthen the edge and protect the cut edge from exposure.

Acceptance

Use of this manual is strictly voluntary. Details that are provided are to be used as a guide only. Details may not be applicable for all situations. This guide provides one standard detail and WSDI accepts that other installation details may be needed and other details may exist. WSDI makes no guarantee as to the Weather Tightness of the system or details found with in this guide. The information in this manual is believed to be correct and accurate at the time of printing. WSDI reserves the right to change details, discontinue products, change designs at any time without incurring obligation. It is best to consult your Design Engineer for recommendations.

Underlayment

There are many types of underlayment's on the market today. All designed with a special purpose depending on the type of Metal and profile. Many different types of metal will require a different type of underlayment, such as A606-4 (Corten) which requires a High Temperature underlayment. WSMR recommends Sharkskin[®] Ultra and/or Sharkskin[®] Ultra SA.

Snow Design

Design and dimension must be the proper width to accommodate high snow, rain, ice, and slope conditions. If possible, splices, penetrations, should be minimized in areas of high snow and ice accumulations. Details found in this manual may not pertain in areas of high snow and ice accumulations.

Panel Coverage and Fastening

T-Groove is available in the following panel widths: 12", 14", 16" and 18" wide. It can also be made with up to a 3" reveal. Custom panel widths are available. Please consult with your WSMR representative for details and fastening recommendations.

Safety and Maintenance

Extreme care should always be used when working with metals. Safety should always be a top priority and approved fall protection and equipment as approved by OSHA should always be used. No structure is immune to severe weather or is completely maintenance free. To keep your siding performing as it was designed, an inspection and comprehensive maintenance program should be implemented.

References

For other installation techniques and details, The Sheet Metal and Air Conditioning Contractors National Association Inc. (SMACNA) and NRCA manuals are great resource for working with sheet metal.

Technical Assistance

Contact your WSDI sales or technical representative for any additional information or assistance. To insure you have the latest information available, please inquire or visit our web sites at www.Westernstatesmetalroofing.com or www.Paintedrustedroofing.com



Finishes You've Never Seen Before®

WESTERN STATES METAL ROOFING

(877) 787-5467 • WESTERNSTATESMETALROOFING.COM

REQUEST A FREE METAL COLOR SAMPLE

Affordable Delivery throughout USA, Canada, and Mexico

Phoenix: 901 W Watkins St., Phoenix, AZ 85007 ☎ (602) 495-0048 ⊠ sales@westernstatesmetalroofing.com

Tucson: 4975 E. Drexel Rd., Tucson, AZ 85706 ☎ (520) 574-4247 ⊠ tucsonsales@westernstatesmetalroofing.com

f	www.facebook.com/westernstatesmetalroofing/
Ø	www.instagram.com/westernstatesmetalroofing/
y	www.twitter.com/weststatesmetal
▶	www.youtube.com/westernstatesmetalroofing
in	www.linkedin.com/company/western-states-metal-roofing
P	www.pinterest.com/westernstatesmetalroofing/
	www.houzz.com/pro/raynaann/western-states-metal-roofing